# AE698A INTRODUCTION TO VIRTUAL INSTRUMENTATION



# TERM PROJECT REPORT ON

"OBJECT TRACKING AND TRAVERSING USING MOTOR"

**Course Instructor** 

Dr. K. Poddar

SUBMITTED BY-Samiksha Nagrare (16101038) Rahul Ranjan (16101034)

## **Acknowledgment**

We are thankful to Dr. Kamal Poddar for explaining us the concepts of virtual instrumentation in a very lucid manner. We are very thankful to the lab assistants, Mr. Nitin and Mr. Rajesh, to make the lab available at almost all the times and helping us in any way possible to help us complete the project. The TA's, without whom the project would never have taken shape as it is now. We thank them for their continuous support in explaining us the details regarding the system and its working.

#### **Abstract**

This project deals with object tracking of an object using the image acquisition module in the following three parts. For the first part, integration of two cameras helped us capturing an object in three dimensional space. Position of the chosen object has been captured in multiple frames in such way that its position and velocity could be found in a particular space frame. The second part gave us approximate coordinates to form a image using the frames captured. These coordinates are utilized to move a traverse through a motor, thus forming the third section to fulfil the objective.

### **Introduction**

Image Acquisition and Processing with LabVIEW combines the general theory of image acquisition and processing. The first step towards any kind of image processing is the acquisition of the actual images to be processed which can be obtained using a camera. It can be chosen between two main types of cameras - analog and digital. National Instruments high-speed image acquisition (IMAQ) devices provide up to 80 MB of onboard memory and they work with motion control and data acquisition hardware.

Some of the instruments used for this project are:

#### (a) Stepper Motor:

Stepper motors move a known interval for each pulse of power. These pulses of power are provided by a stepper motor driver and is referred to as a step. When 360° of a circle is divided by the step angle gives the number of steps per revolution. Here, the 360° of the circle is divided into 20000 steps i.e. with one input pulse the motor will rotate 0.018°.





fig. Stepper motor (L) and its needle pointer that rotates (R)  $\,$ 

#### (b) Stepper Motor Driver:

The stepper motor driver used in this program is named as RMCS-1102, developed by Rhino Motion Controls. It designed for smooth and quiet operation without compromising on torque and control at higher speeds. It achieves micro-stepping using a synchronous PWM output drive.

The first 6 terminals of 12 are used for pulse and direction combination and the first 4 out of 8 switches are used for specifying different step resolutions. Tables (1) and (2) shows these terminals and switches respectively.

| Terminal no. | Terminal name | Description                                     |  |
|--------------|---------------|---|--|
| Terminal 1   | ENA-          | Enable(motor free) -ve optically isolated input |  |
| Terminal 2   | ENA+          | Enable(motor free) +ve optically isolated input |  |
| Terminal 3   | DIR-          | Direction -ve optically isolated input          |  |
| Terminal 4   | DIR+          | Direction +ve optically isolated input          |  |
| Terminal 5   | PUL-          | Pulse -ve optically isolated input              |  |
| Terminal 6   | PUL+          | Pulse +ve optically isolated input              |  |

table (1): First 6 Terminals

| Steps/rev | SW1 | SW2 | SW3 | SW4 |
|-----------|-----|-----|-----|-----|
| 200       | ON  | ON  | ON  | ON  |
| 400       | OFF | ON  | ON  | ON  |
| 800       | ON  | OFF | ON  | ON  |
| 1000      | OFF | OFF | ON  | ON  |
| 2000      | ON  | ON  | OFF | ON  |
| 3200      | OFF | ON  | OFF | ON  |
| 4000      | ON  | OFF | OFF | ON  |
| 8000      | OFF | OFF | OFF | ON  |
| 1600      | ON  | ON  | ON  | OFF |
| 6400      | OFF | ON  | ON  | OFF |
| 10000     | ON  | OFF | ON  | OFF |
| 12000     | OFF | OFF | ON  | OFF |
| 12500     | ON  | ON  | OFF | OFF |
| 12800     | OFF | ON  | OFF | OFF |
| 16000     | ON  | OFF | OFF | OFF |
| 20000     | OFF | OFF | OFF | OFF |

table (2): First 4 Switches




Fig. Stepper Motor Driver

# **VIs and Functions Used**

## (A) IMAQ functions used:

| <u>Sr.</u><br><u>No.</u> | <u>Name</u>                 | <u>Block</u>  | <u>Function</u>  |
|--------------------------|-----------------------------|---|--|
| 1                        | IMAQ find<br>circles VI     | Image Src Image Dst Out Image Dst Out Nb Circles Circles Data error in (no error) Max Radius      | Separates overlapping circular particles and classify them based on their surface area, radius and perimeter.  |
| 2                        | IMAQ<br>Threshold<br>VI     | Keep/Replace Value (Replace)  Image Src  Image Dst Out  Range  error in (no error)  Replace Value | Applies threshold to a VI. Converts grayscale image to binary image.   |
| 3                        | IMAQ<br>create VI           | Border Size  Image Name error in (no error) Image Type  | Creates a temporary memory location for image.   |
| 4                        | IMAQ Cast<br>Image VI       | # Shifts Image Src Image Dst Out Lookup Table error in (no error) Image Type                      | Converts the current image type to the image type specified by Image Type.   |
| 5                        | IMAQdx<br>Open<br>Camera VI | Camera Control Mode Session In Session Out error in error out                                     | Opens a camera, queries<br>the camera for its<br>capabilities, loads a<br>camera configuration<br>file, and creates a unique<br>reference to the camera. |
| 6                        | IMAQdx<br>Close<br>Camera   | error in error out  | Stops an acquisition in progress, releases resources associated with an acquisition, and closes the specified Camera Session.                            |

| 7 | IMAQdx<br>Configure<br>Grab VI | Session In Session Out  | Configures and starts a grab acquisition. Use the grab VI for high-speed image acquisition and to copy an image out of the buffer. |
|---|--------------------------------|---|--|
| 8 | IMAQdx<br>Grab VI              | Session In Image In Image Out Wait for Next Buffer? (Yes)  error in Error out | Configures and starts a grab acquisition. Use the grab VI for high-speed image acquisition and to copy an image out of the buffer. |
| 9 | IMAQ<br>Dispose VI             | All Images? (No)  Image error in (no error)                                   | Destroys an image and frees the space it occupied in memory.   |

## (B) Data Acquisition blocks:

| <u>Sr.</u><br><u>No.</u> | <u>Name</u>  | <u>Block</u>   | <u>Function</u>  |
|--------------------------|--|--|--|
| 1                        | DAQmx<br>Create<br>Channel   | input terminal configuration minimum value maximum value task in physical channels name to assign units error in custom scale name | Create virtual channel or set of virtual channels and adds them to a task.   |
| 2                        | DAQmx<br>Timing  | samples per channel sample mode task/channels in error in  | Configures the number of samples to acquire or generate and creates a buffer when needed.  |
| 3                        | DAQmx<br>Start<br>Task   | error in error out   | Transitions the task to the running state to begin the measurement or generation.  |
| 4                        | DAQmx Stop Task  task/channels in page task out error in error out |  | Stops the task and returns it to the state the task was in before the DAQmx Start Task VI ran or the DAQmx Write VI ran with the auto start input set to TRUE. |

| 5 | DAQmx<br>Write | auto start task out task/channels in number of samples written error in | Writes samples to the task or virtual channels you specify. |
|---|----------------|---|---|
| 6 | DAQmx<br>Clear | error in error out  | Clears the task.  |

## **Block Diagrams**

### 1) Image Acquiring VI

- Figure 1 shows the block diagram for image acquiring.
- This VI uses image acquisition functions to acquire, transmit, etc. the photographs of the object to be tracked.
- Using configure grab and grab, we acquire images continuously instead of using 'snap' directly because images would suffer from delayed input.
- We acquire coloured images and then using cast image we convert them from 32 bit to a 8 bit image.
- Now using threshold, we convert this to binary image in such a way that there would be at least a minimum and maximum threshold of 0 and 255 pixels respectively.
- To make things simpler, we have considered a black coloured background to ignore the filter usage.
- Using IMAQ find circle, this program identifies the image as a circular object of which we get an array of cluster containing its x and y coordinate, radius and its surface area.
- Using these coordinates, we plot the motion of the particle, viz., tracking.
- Using data socketing, the value get passed to another VI for motor control and traversing purpose.





Figure 1: Block Diagram for acquiring continuous images and plotting its (x-y) motion in graph

#### 2) Stepper VI

- Figures 2,3 and 4 shows the block diagram for stepper VI.
- This VI uses a stack sequence, three case structure and two while loops to initialize and process to obtain required results.
- Here, we initialized a digital line so as to give initial instructions to motor on how to rotate. It's clockwise when the switch is OFF and counter clockwise if it is ON.
- The stepper motor used has been given a setting of 20,000 steps per rotation. Hence, each step gives an accuracy of 0.018 degrees.
- Also, we initialize the stepper motor and bring it on zero position if it is not and we check whether the task has been completed. This is done in the first frame of the stacked sequence.
- Now the position of the object obtained via data socketing is compared with the initial position
  and if the difference is obtained, the motor starts traversing the object. It is to be noted that if
  positive difference is obtained, then the motor will run clockwise and if it is negative, it will run
  counter clockwise.
- The shift register will pass value of the previous object position obtained and it is subtracted from the new object's position.
- This process will continue till the difference becomes zero.
- Zero difference indicates the position that we were focused to achieve is reached, i.e., it has traversed the x position.

Figure 2: Block Diagram for Controlling the direction of motion of the Stepper Motor






Figure 3: False Case of the second-case structure




Figure 4: False Case of the First Case Structure

## **Future scope**

- This principle could be extended to three dimensional axes so that we can obtain any objects' mechanical action. This could then be used to obtain the size of the object and control the motion of any autonomous vehicle.
- Frequency of the motor which is given in revolutions per seconds can also be controlled depending upon the speed of the moving object.